

BSM (Balance Shaft Module)

- Located in oil pan – absorb vibration
- Oil pump is installed in BSM
- Timing mark and Timing chain

